

H-PANEL CONTROL INTERCONNECTIONS

Notes:

1. Spare Outputs are Standard on Industrial Product Only. GenLink® Required for Programming. Contacts Rated at 5A at 30VAC/30VDC
2. TB4 Max Wire Size: #10 AWG, Recommended Tightening Torque: 14 LB-IN
3. TB1, TB2, TB9 & RB3 Max Wire Size: #14 AWG, Recommended Tightening Torque: 12 LB-IN
4. Refer to H-Panel Manual for Instructions on Enabling HTS Transfer Switch. Refer to HTS Transfer Switch Manual for Dip Switch Settings for Multiple HTS Application
5. Connect the RS-485 Overall Shield at Genset Connection Terminal Only

